

BakkerElkhuizen UltraBoard 950 compact keyboard

User Manual



Work Smart - Feel Good



This is an English quick-start guide. Instructions for other languages can be found at our website: www.bakkerelkhuizen.com.

The UltraBoard 950 in short


Thank you for purchasing the Ultraboard 950 Compact Keyboard. This space-saving keyboard is designed for Windows* based PC's. We sincerely hope you will enjoy using it.

This quick-start guide will help you configure and use your new keyboard. Here are a few features of the UltraBoard 950:


- Space-saving compact design.
- Wired keyboard
- Connect peripheral devices via the 2 port USB hub.
- Scissor action keys with a finger friendly surface for high comfort and reduced tiredness when typing.
- Ultra-thin and height adjustable for enhanced comfort.
- 4 shortcut keys, Home, Mail, PrtScr and NumLock for fast working.
- Integrated multimedia keys.

Overview of the UltraBoard 950

- 1 Hotkeys
- 2 Status LEDs
- 3 Integrated NumLock keys
- 4 Multimedia keys
- 5 Height adjustable feet
- 6 USB Hub



LED Indication



LED (Green)


Power on – LED in solid green when Keyboard is active

LED (Green)

NumLock – LED in solid green when NumLock is active

LED (Green)

CapsLock – LED in solid green when CapsLock is active




Getting Started

1. Connect the Ultraboard Compact keyboard to your PC with the integrated USB plug.
2. This keyboard is “plug & play” so wait for a few seconds for your computer to detect the device and then you’re free to start typing.
(Please note that the first time you connect your new keyboard, your operating system automatically installs the required driver. This process can take a few seconds.)
3. When installation is complete your keyboard is ready for use.

How to use Fn key with numpad & multimedia keys

Numpad

Ensuring NumLock is ON holding the Fn key will activate the small light blue numbered keys for use.



Multimedia keys

Function keys of F7, F8, F9, F10, F11, F12 keys support Windows for multimedia use. Hold the Fn key and press F7 to F12 to use these functions.

F7	Previous Track
F8	Play/ Pause
F9	Next Track
F10	Mute
F11	Volume Down
F12	Volume Up

BakkerElkhuiZEN

Taalstraat 151

5261 BC Vught

The Netherlands

tel. +31 36 546 7265

fax. +31 36 546 7830

email. info@bakkerelkhuiZEN.com

All rights reserved. All trade names are registered trademarks of the respective manufacturers listed. All specifications are subject to change without prior notice.